INSTRUCTIONS FOR COLLECTING COMPLIANCE WATER SAMPLES FOR Phase V Extended Inorganics

TE3

Note: Sample kits are pre-coded and can be used only for the tests and public water systems listed. Do not change the test codes or switch the paperwork or bottles from other sample kits.

- 1. Collect samples (ALL THREE BOTTLES) at the sample point preprinted on the sample form.
- 2. Remove any screen, hoses and aerators from end of faucet.
- 3. Run COLD water for 3 to 5 minutes to make sure water has not been sitting for a long time in pipes or tanks and is fresh from the well.
- 4. Turn water down so it does not splash.
- 5. Uncap bottle and fill to shoulder with water. Screw the cap on tightly.
- 6. Freeze cool-pack and replace in shipping container just prior to shipping.
- 7. Fill out the required information on sample form. **SIGN THE FORM!** The sample will not be processed unless the form has a signature!
- 6. Return bottle with completed paperwork to lab. If mailed, use the enclosed label "Water Sample First Class Non-PMPC Direct to Augusta." **SAMPLE MUST ARRIVE AT LAB WITHIN 7 DAYS OF COLLECTION!**

IF YOU HAVE ANY QUESTIONS....PLEASE CALL THE MAINE DRINKING WATER PROGRAM AT (207) 287-2070 OR THE LABORATORY AT (207) 287-1716.

NOTE: If you do not want to use the Health & Environmental Testing Laboratory for your water testing, or do not wish to be on the automatic shipping list for sample kits, please return this kit and paperwork to the laboratory.